

Swispumps



Contents:

1. Wall Mounted Pump.
2. 5 Ft. Material Hose.

Instructions:

1. Inspect all the fittings, screws, and nuts before mounting.
2. Find a suitable or permanent location to mount your SWISPUMP.
3. Insert the material hose into the barb underneath the pump and make sure is tight.
4. Place underneath the pump the catalyst container you wish to use. Insert the material hose inside the container and begin to pump.

Instrucciones: (Spanish)

1. Este seguro que todos los tornillos, tuercas y juntas estén bien apretadas.
2. Encuentre un lugar adecuado y permanente para montar la bomba.
3. Inserte la manga para el material en la junta debajo de la bomba.
4. Coloque el recipiente del catalizador debajo de la bomba, y inserte la manga adentro.

If you have any questions regarding the use of other materials, please feel free to contact us at
800-553-7634.